


Mount Hopper Cover Centrally on Angle Crossmembers

ISSUED FOR MANUFACTURE


		DIMENSIONS IN MILLIMETERS DO NOT SCALE		Material Working Tolerance C = ± 0.25 UNO ES = ± 0.1 UNO S = 20 ± 4.0 SS/UNO	Surface Finish 3.2 UNO
Drawn	10/01/2005	Checked	TJP	Design	Released
Eng. App.		Eng. App.	SKR	Drawn	
Qty. App.		Qty. App.	JES	Scale	
Cost Center		Cost Center		Scale	
Scale		Scale		Scale	
Rev	Change	Date	By	Rev	Iss. Control

©
ROESNER PTY. LTD. PH 08 9729 1801
MULTISPREAD-980T
HOPPER & COMPONENTS
ASSEMBLY

A3 **M03-3-00-00** Rev No: **1** Iss No: **1/2**



A (0.40 : 1)



M16 Bolt Fastened to Angle Crossmember
Use Split Pin to hold Hopper Cover in place

ISSUED FOR MANUFACTURE

	DIMENSIONS IN MILLIMETERS		Name: Working Tolerance D = ± 0.25 UNO DD = ± 0.1 UNO DD = ± 0.05 UNO	
	DO NOT SCALE		Surface Finish: 3.2 UNO Date: 10/01/2005 Name: matt Checked: TJP Eng. App: SHR Mfg. App: JRR	
Design: Released Drawn: [blank] Date: [blank] Draw Location: [blank]		Change No. [blank]		
Rev	Change	Date	Name	Rev No. 1 Sh No. 2/2

ROESNER PTY. LTD. PH 08 9729 1551

MULTISPREAD-980T
HOPPER & COMPONENTS
ASSEMBLY

A3 M03-3-00-00 1 2/2

File No. 1.0300000000000000